

KEYPAD HARD RESET:

Wire link in to EG IN (bottom corner)

Touch the other end of the wire off GND (beside DOOR SENS)- the keypad will beep once

Power off for ONE MINUTE

Power on and make the same link- the keypad will beep twice

Now enter 8080** to get in to programming mode (solid amber LED)

Enter 01 0000 # to set Engineers code to default

Enter ** to exit programming mode

CELLCOM PLUS/PRIME HARD RESET:

Power off

Make a link across the terminals marked OPEN. Or EG

Switch on power

After several seconds the relay will click

The unit will then clear memory and be defaulted

Remove the link and wait around 20 seconds

Reboot the unit for good measure

CELLCOM HARD RESET:

Power off the GSM-PCB for one minute

Power the PCB back on

Then link a wire between the PB and the GND terminals on the GSM-PCB

Once this is done press and hold the small red/white micro switch for 10 seconds until the unit beeps to confirm reset. (You would want to have this pressed and held down before you get the boot up confirmation from the PCB)

Then remove the link and send an SMS with the standard *12*1234# passcode